

## **Operating instructions**

### **AVM – system remote control RC3**




AVM Next Generation GmbH, Daimlerstraße 8, 76316 Malsch

## Using the remote control

The RC3 is an infrared remote control. It works up to distances of 7 meters. For best function point with the RC3 to the front panel of your hi-fi set. If the hi-fi set doesn't react or reacts only over short distances, the batteries of the RC3 must be changed.

## Changing batteries



Bottom view

Unscrew the 6 marked screws (CAUTION, do NOT unscrew the 2 unmarked screws in the middle). Take the bottom plate with the mounted pcb out. Remove the worn batteries and replace them with two new batteries (type CR2032, 3V Lithium cells). Make sure that polarity is correct (the "+" sign must be on top). Insert the bottom plate and screw it tight.

## Declaration of conformity (for EC only)

We herewith confirm, that the unit to which this manual belongs fulfills the EC rules necessary to obtain the sign



the necessary measurements were taken with positive results.

**AVM Next Generation Audio Technologies GmbH,  
Daimlerstraße 8, D-76316 Malsch, Germany**

